




del País Vasco

Unibertsitatea

Residual Gas Ion Spectrometer v4 January 2012

by J. Pozimski, P. Savage, I. Clark & S. Alsari





A design based closely on RGIS3 by R. Doelling, PSI

The RGIS4 will tell us the energy of the particles entering the instrument. It will be located in the drift vessel between LEBT solenoids 2 and 3.


The space charge decompensation electrode has shown that the beam is affected very quickly by the presence of a voltage and is slower to recover to its original state.

The time taken for the beam to recover is a function of the gas pressure around the beam and of the species of gas present.


For an uncompensated or partly compensated beam the RGIS4 should collect electrons produced by the FETS H⁻ beam. If the compensation exceeds 100% it should collect positive gas ions.

Understanding the factors affecting the beam recovery time could be particularly important to ESS and Fermilab who are both interested in chopping their beam in the LEBT.



















Set outer bend to +ve voltage and inner bend to – ve voltage to detect positively charge particles (in our case, – residual gas ions)

Reverse the polarity to detect negatively charge particles (in our case, electrons)













The air side BNCs have been labelled 1, 2, 3 and 4 and this corresponds to:

- 1) Faraday cup
- 2) Inner bend
- 3) Outer bend
- 4) Spare (unused).


Each brass connector that is soldered to the lead has the corresponding number of notches machined into it for identification on assembly.








Relation between particles energies detected and voltage on electrodes






Resolution of spectrometer and transfer function





Keithey 6487 provides deflection voltage and ammeter and is controlled by a Labview code measurements





Labview code allows for automatic spectrometer measurements

ject Operate Iools Window Help		▶ Search
Step Voltage Suppy with Current Readings This Model Created by Saad Alsari on January 2012 as part of the FETS project Work		
ASRL4::INSTR	MODEL 6487	
Start Stop Ramp output action \$0.00 \$0.00 \$Auto Sync Enabled Number of steps equals the sample count Start action	Voltage Plot	
trigger source Filter Type trigger delay (sec)	35E+0- 30E+0- 25E+0- 20E+0- 20E+0-	*****
measurement delay (sec) \$ b.0000 measurement function sample count actual number of readings \$ DC Current \$ 51	19540- 10040- 5840- 0640-	30 32 34 36 38 40 42 44 46 48 50
	Current Plot	
	-1E-6 -	
	-1E-6-	
	-1E-6 - -2E-6 - 0 2 4 6 8 10 12 14 16 18 20 22 24 26 28	: 30 32 34 36 38 40 42 44 46 48 50
Record Current to file Press the button below to record thecurrent readings (in A) to the specified file file path (dialog if empty) %C:\DataCurrent2012.txt		

Slide 13 of 14



Next steps

- 1. Installation in FETS vacuum test COMPLETE
- 2. Installation of electronics (Keithley) first tests with beam
- 3. Installation of decompensation electrode
- 4. First set of compensation measurements (March?)
- 5. If Keithley ammeter is not sufficient
 - 1. Attach DDC 112 setup to FDC
 - 2. Upgrade to Channeltron
- 6. Second set of compensation measurements (May)
- 7. Can be used later in MEBT (different time structure) if CF 100 flange is available.